# GNSS INLINE AMPLIFIERS

SIGNAL LOSS SOLUTIONS

STARLINK<sup>™</sup> INLINE AMPLIFIERS PROVIDE A SIMPLE AND COST EFFECTIVE MEANS TO MAXIMISE THE PERFORMANCE OF YOUR GNSS SYSTEM



### SIGNAL LOSS ISSUES

GNSS signals become attenuated as they travel through long cable runs, this reduced signal gain can limit the ability of the receiver to provide a position solution to the point where the signal is completely undetectable by the receiver. Receivers specify an ideal gain strength to ensure the most robust positioning; a long cable run can result in a signal reaching the receiver that is below the ideal strength required.

### **AMPLIFIED SOLUTIONS**

The level of signal loss depends on the quality and length of cable used. When looking at the common RG-58 cable type a cable length exceeding 30 metres can result in a signal loss issue. StarLink inline amplifiers address this problem by amplifying the GNSS signal to provide increased gain, reducing the effects of attenuation. With the correct amplification, it is possible to extend antenna cable runs significantly. Higher specification cables can enable greater distances to be achieved.





**Connectivity options** 



Small form factor

Multi-frequency and constellation

GPS L1/L2/L5 GLONASS G1/G2 Galileo E1/E5a/E5b/E6 BeiDou B1/B2 Upper Band Correction Signals

### **INTERFERENCE MITIGATION**

Weak GNSS signals are vulnerable to interference, an issue addressed as StarLink inline amplifiers filter and reject unwanted interference, reducing the effect of internally generated electrical noise, whilst enabling GNSS signals to pass through.

# RUGGED, ADAPTABLE AND EASY TO INSTALL

StarLink inline amplifiers are made with gold plated brass and rugged and watertight packaging. They are available with SMA, TNC, BNC, or N connectors.

Installation is a simple process just attach the amplifier in line with your antenna cable. The amplifier uses the same power as the antenna so no extra power source is required. All StarLink products come with a full, one year parts and labour warranty.

ORSBERG



www.forsbergpnt.com +44 (0)1524 383320 info@forsbergpnt.com



## info@forsbergpnt.com

# **INLINE AMPLIFIER SPECIFICATIONS**

### **GENERAL INFORMATION**

B3, IRNSS, QZSS L6, SBAS, L-BAND)

MODEL 112

13dbB Gain +/- 2dB

LA-12-L1L2-N

LA-12-L1L2-TS

14dB

1176MHz 1201MHz

PPP

Services

1539MHz

1557MHz

14dB

Inline Amplifiers with TNC connectors are 3.770" in length. Length will vary slightly with "N" and "SMA" connectors installed. Power consumption 8mA.

CONNECTORS

N type, female

TNC type to SMA type female

(GPS L1/L2/L5, GLONASS G1/G2/G3, GALILEO E1/E5/E6, BEIDOU B1/B2/

- Typical Noise figure for 1575 Inline Amplifiers is <3dB.
- Typical Noise figure for L1L2 Inline Amplifiers is <4dB.
- Input voltage for all models is from 3 to 28 VDC. Current draw is <10ma.
- Operating temperature is -55°C (-67°F) to +70°C (158°F)
- Storage temperature is -55°C (-67°F) to +85°C (185°F)
- Relative humidity 0 100% condensing.
- IP Rating: IP67

#### CONNECTORS

(GPS L1, GLONASS G1, GALILEO E1, BEIDOU B1, SBAS, L-BAND)

#### 15dB Gain +/- 1dB

**MODEL 1575** 

LA-12-1575-100-N LA-12-1575-100-S LA-12-1575-100-T LA-12-1575-100-B LA-12-1575-100-TMF LA-12-1575-100-BT LA-12-1575-100-TS


## 20dB Gain +/- 1dB

LA-21-1575-100-N LA-21-1575-100-S IA-21-1575-100-T LA-21-1575-100-B LA-21-1575-100-TMF LA-21-1575-100-BT LA-21-1575-100-TS

N type female both ends SMA type female both ends TNC type female both ends BNC type, female TNC type, male to female BNC type to TNC type female TNC type to SMA type female

FORSBERG STARLINK

N type female both ends SMA type female both ends TNC type female both ends BNC type, female TNC type, male to female BNC type to TNC type female TNC type to SMA type female





© Forsberg Services Ltd. 2020



Rev. 14/04/2020





GPS L1

1575MHz

1227MHz

LA-21-L1L2-TS TNC type to SMA type female dB gain from StarLink L1L2 Inline Amplifiers Gal E5a Gal E5b BD B3 IRNSS **BD B2** 19dB



G2

Gal E6

1279MHz

GLO

G1

1602MH

-L1L2.12

13dB

\_L1L2.21 -L1L2,12

11dB

#### LA-12-L1L2-S SMA type, female LA-12-L1L2-B BNC type, female LA-12-L1L2-T TNC type, female LA-12-L1L2-TMF TNC type, male to female I A-12-I 1I 2-BT BNC type to TNC type female

20dB Gain +/- 1dB LA-21-L1L2-N N type, female SMA type, female LA-21-L1L2-S BNC type, female IA-21-I12-B LA-21-L1L2-T TNC type, female LA-21-L1L2-TMF TNC type, male to female LA-21-L1L2-BT BNC type to TNC type female